

OR Resources

Instructions for making sterile saline

- Place 6 saline bottles upside down in a large tub/container filled with ice.
- Cover the ice with rubbing alcohol (three bottles).
- Shake the bottles every 15 minutes or ice will form in the opening and the it will not come out.
- Start process 30 minutes before a Brain Death organ recovery or an hour before a Donation after Circulatory (DCD) death recovery.

